

LOC I-BAF <u>111.9</u>	APP CRS 204°	Rwy Ldg 8919 TDZE 270 Apt Elev 270
----------------------------------	------------------------	---

ILS or LOC RWY 20
WESTFIELD-BARNES RGNL (BAF)

T Circling kwy 15 NA at night. DME from BAF VORTAC. DME use requires simultaneous reception of I-BAF and BAF DME. For inop ALS, increase S-ILS 20 Cat E visibility to RVR 4000; increase S-LOC 20 Cat E visibility to 3 SM; increase PETGE fix minimums S-LOC 20 Cat E visibility to 1 1/2 SM.

MALSR

A5

T

MISSED APPROACH: Climb to 1300 then climbing right turn to 4000 direct CTR VOR/DME and hold, continue climb-in-hold to 4000.

ATIS 127.1 263.15	BRADLEY APP CON 125.35 281.5	WESTFIELD TOWER ★ 125.075 (CTAF) 0 251.1	GND CON 121.7 289.4
------------------------------------	---	---	--------------------------------------