WORTH ONE DEPARTURE

(WORTH1.TTT) 25JAN24

LANCASTER, TEXAS

LANCASTER RGNL (LNC)

RADAR and DME required.

TOP ALTITUDE: ASSIGNED BY ATC

LONE STAR DEP CON
125.2 343.65
CTAF
122.7

PANHANDLE
116.6 PNH
Chan 113

CHILDRESS
117.0 CDS
Chan 117

WICHITA FALLS
112.7 SPS
Chan 74

TEXICO
112.2 TXO
Chan 59

LUBBOCK
109.2 LBB
Chan 29

CORONA
115.5 CNX
Chan 102

ABILENE
113.7 ABI
Chan 84

MILLSAP
117.7 MQP
Chan 124

MAVERICK
113.1 TTT
Chan 78

SCABI

FERRA

PODDE

V114 R-118 5300 297° (87)

R-127 *14000 *3200 307° (61)

R-233

R-124 5900 305° (66)

V62

R-088 FL180 272° *9300 (192)

R-114 14000 *4800 296° (127)

V62

V66 3700 253° (96) R-071

R-081 3000 261° (13)

129 14000 *3000 285° (92)

4000 *2400 285° (37)

3500 *2800 250° (36)

1800 314°

MSA TTT 25 NM
2700
090° 270°
3600

N

NOTE: PODDE Transition: ATC assigned.

TAKEOFF MINIMUMS
Rwy 13: NA-ATC.
Rwy 31: 300-1¼ or standard with minimum climb of 205'/NM to 800, or alternatively, with standard takeoff minimums and a normal 200'/NM climb gradient, takeoff must occur no later than 1300' prior to DER.

(CONTINUED ON FOLLOWING PAGE)

NOTE: Chart not to scale.

WORTH ONE DEPARTURE

(WORTH1.TTT) 26246

LANCASTER, TEXAS

LANCASTER RGNL (LNC)

AL-5936 (FAA)

DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 31: Climb on heading 314° to 1800 before turning left.

When entering controlled airspace, fly assigned heading for RADAR vectors to appropriate route. Maintain ATC assigned altitude.

ABILENE TRANSITION (WORTH1.ABI): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC.
CHILDRESS TRANSITION (WORTH1.CDS): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC.
CORONA TRANSITION (WORTH1.CNX): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC.
LUBBOCK TRANSITION (WORTH1.LBB): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC.
PANHANDLE TRANSITION (WORTH1.PNH): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC.
PODDE TRANSITION (WORTH1.PODDE): From over TTT VOR/DME on TTT R-250 to PODDE.
TEXICO TRANSITION (WORTH1.TXO): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.

SC-2, 29 OCT 2026 to 26 NOV 2026