WORTH ONE DEPARTURE

(WORTH1.TTT) 25JAN24

GRAND PRAIRIE MUNI (GPM)

GRAND PRAIRIE, TEXAS

RADAR and DME required.

TOP ALTITUDE: ASSIGNED BY ATC

LONE STAR DEP CON
135.975 379.9
GND CON
121.15
GRAND PRAIRIE TOWER★
128.55 (CTAF)

PANHANDLE
116.6 PNH
Chan 113

R-118 V114 5300 297° (87)

CHILDRESS
117.0 CDS
Chan 117

WICHITA FALLS
112.7 SPS
Chan 74

TEXICO
112.2 TXO
Chan 59

R-124 5900 305° (66)

R-127 *14000 *3200 307° (61)

R-233

SCABI

V62

LUBBOCK
109.2 LBB
Chan 29

R-088 FL180 272° *9300 (192)

CORONA
115.5 CNX
Chan 102

R-114 *14000 *4800 296° (127)

129 14000 *3000 285° (92)

FERRA

4000 *2400 285° (37)

MAVERICK
113.1 TTT
Chan 78

3500 *2800 250° (36)

3000 261° (13)

PODDE

V66 3700 253° (96)

R-081

R-071

V62

NOTE: PODDE Transition: ATC assigned.

ABILENE
113.7 ABI
Chan 84

MILLSAP
117.7 MQP
Chan 124

TAKEOFF MINIMUMS
Rwy 36: NA-ATC.
Rwy 18: Standard.

192° 2500

N

MSA TTT 25 NM
2700
090° 270°
3600

(CONTINUED ON FOLLOWING PAGE)

NOTE: Chart not to scale.

WORTH ONE DEPARTURE

(WORTH1.TTT) 26246

GRAND PRAIRIE MUNI (GPM)

GRAND PRAIRIE, TEXAS

AL-9209 (FAA)

DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 18: Climb on heading 192° to 2500 before proceeding on course.

When entering controlled airspace, fly assigned heading for RADAR vectors to appropriate route. Maintain ATC assigned altitude.

ABILENE TRANSITION (WORTH1.ABI): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC.
CHILDRESS TRANSITION (WORTH1.CDS): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC.
CORONA TRANSITION (WORTH1.CNX): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC.
LUBBOCK TRANSITION (WORTH1.LBB): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC.
PANHANDLE TRANSITION (WORTH1.PNH): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC.
PODDE TRANSITION (WORTH1.PODDE): From over TTT VOR/DME on TTT R-250 to PODDE.
TEXICO TRANSITION (WORTH1.TXO): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.

SC-2, 29 OCT 2026 to 26 NOV 2026