

CONTINUED FROM PRECEDING PAGE

RCO 122.6 (COLD BAY RADIO)

Ⓡ ANCHORAGE CENTER APP/DEP CON 121.4

RADIO AIDS TO NAVIGATION: NOTAM FILE DUT.

DUTCH HARBOR NDB/DME (HW) 283 DUT Chan 86 N53°54.31' W166°32.87' at fld. 272/9E.

DME portion unusable:

005°-080°

081°-330° byd 13 NM

331°-004° byd 15 NM

COMM/NAV/WEATHER REMARKS: For a toll free call to Cold Bay FSS dial 1-800-478-7250. For a toll free call to Kenai FSS dial 1-866-864-1737. Wx information avbl on 129.5 (call sign Dutch WX) or ph: 907-581-1256, 1645-0345Z. Cold Bay FSS oprs 1700-0300Z, all otr times Kenai FSS.

UPPER WASILLA LAKE SPB (See WASILLA on page 257)

UTOPIA CREEK N65°59.71' W153°41.63' NOTAM FILE UTO.

FAIRBANKS

NDB/DME (HW) 272 UTO Chan 22(Y) 264° 14.2 NM to Hughes. 983/17E.

L-41

NDB unusable:

210°-240°

340°-355°

NDB/DME unusable:

45-105 byd 25 NM

105-45

UTQIAGVIK

WILEY POST-WILL ROGERS MEML (BRW)(PABR) 0 SE UTC-9(-8DT) N71°17.09' W156°46.12' POINT BARROW

49 B ARFF Index—See Remarks NOTAM FILE BRW

H-1A, L-41

RWY 08-26: H7100X150 (ASPH-GRVD) S-75, D-160, 2D-300

IAP

PCN 43 F/A/X/U HIRL

RWY 08: MALSR. PAPI(P4R)—GA 3.0° TCH 51'. RVR-T Thld dsplcd 600'. Rgt tfc.

RWY 26: REIL. PAPI(P4L)—GA 3.0° TCH 50'. RVR-R Thld dsplcd 600'. Antenna.

RUNWAY DECLARED DISTANCE INFORMATION

RWY 08: TORA-7100 TODA-7100 ASDA-6500 LDA-5900

RWY 26: TORA-7100 TODA-7100 ASDA-6500 LDA-5900

SERVICE: S2 FUEL 100LL, JET A1 LGT ACTVT MALSR Rwy 08; REIL Rwy 26—CTAF. HIRL Rwy 08-26 preset low instst—incr instst BRW FSS 1500-0700Z; aft hr—CTAF. PAPI Rwy 08 & 26 on consly. Rotg bcn on consly.

AIRPORT REMARKS: Attended 1500-0530Z. Waterfowl invof arpt

Spring-Fall. Class I, ARFF Index B. Clsd to acr ops more than 30 pax seats excp PPR in writing - Airport Manager P. O. Box 367 Barrow, AK 99723. Rcmd lgr acct use elephant ear to turn around. Main ramp bld non std wingtip clnc; rwy back taxi when lgr acct prkd on main ramp. Snow removal, wildlife ctl, cond rptg & arpt maint svc avbl durg maint duty hr 1500-0530Z; aft hr—AMGR. Arpt sand lgr gradation than FAA rcmd/see AC150/5200-30. TSA reg arpt; See 49 CFR 1542. Gates & doors must be secured at all times. Tsnt - AMGR or BRW FSS for info. NOTE: See Notices—Drone Activity at Coastal Airport Launch Sites.

AIRPORT MANAGER: 907-852-5851

WEATHER DATA SOURCES: ASOS 132.150 (907) 852-3112. (WX CAM)

COMMUNICATIONS: CTAF 123.6 AFIS 132.15 (1500-0700Z; OT ctc Fairbanks FSS)

FSS BRW (BARROW) 1500-0700Z; OT ctc Fairbanks FSS.

BARROW RADIO 121.5 122.2 122.6 123.6 (LAA 123.6)

ANCHORAGE CENTER APP/DEP CON 135.3

AIRSPACE: CLASS E svc continuous.

RADIO AIDS TO NAVIGATION: NOTAM FILE UTO.

ILS/DME 110.5 I-BRW Chan 42 Rwy 08. Class IE. Localizer backcourse unusable 2.2 DME abv 2,050' and at 1.0 DME abv 1,050'. Autopilot coupled apchs not applicable blw 290' MSL.

COMM/NAV/WEATHER REMARKS: For local call to Barrow FSS call 907-852-2511. For a toll free call to Fairbanks FSS call 1-866-248-6516. WSO 907-852-6484. AFIS operd by BRW FSS when open, OT Fairbanks FSS.

