

## CONTINUED FROM PRECEDING PAGE

**RADIO AIDS TO NAVIGATION:** NOTAM FILE FAI.

(H) (H) VORTACW 108.6 FAI Chan 23 N64°48.00' W148°00.72' 056° 4.1 NM to fld. 1526/21E.

TACAN AZIMUTH unusable:

065°-100° byd 30 NM

270°-330° byd 10 NM blo 10,000'

270°-330° byd 30 NM

CHENA NDB (HW) 257 CUN N64°50.32' W147°29.70' 245° 9.4 NM to fld. 462/17E.

ILS/DME 109.1 I-CNA Chan 28 Rwy 02L. Class IIIE. DME unusable byd 025° left of course.

ILS/DME 110.3 I-FAI Chan 40 Rwy 20R. Class IIE.

**COMM/NAV/WEATHER REMARKS:** For a toll free call to Fairbanks FSS dial 1-866-248-6516, for a local call to Fairbanks FSS dial (907) 474-0137. TACAN located N64°48.01' W148°00.81'. (Although collocated facilities antennae are at different positions). For flights in MOA's east of Fairbanks recommend contacting Eielson Range Control on 125.3/126.3 or call 1-800-758-8723 for information on military activities. NWS weather balloon launch site 2000 feet west of midfield Runway 02L-20R. Launches are twice daily at 1100 and 2300 UTC.

**WATERWAY 02W-20W:** 5400X100 (WATER)

**WATERWAY 02W:** Fence.

**WATERWAY 20W:** Fence.

**SEAPLANE REMARKS:** SPB controlled by Fairbanks Intl ATCT. Ctc ATCT on freq 118.3 as soon as practical after start up for taxi on the pond. Float pond tfc as assigned by Fairbanks ATCT. Limited transient float plane parking avbl, ctc 907-455-4571 for information. Sfc frozen in winter, not monitored.

**GOLD KING CREEK** (AK7)(PAAN) 39 SE UTC-9(-8DT) N64°11.88' W147°55.72' **FAIRBANKS**

1720 NOTAM FILE FAI

**RWY 09-27:** 2558X17 (GRVL-DIRT)

**RWY 09:** Trees.

**RWY 27:** Brush.

**AIRPORT REMARKS:** Unattended. Rwy condition not monitored, recommend visual inspection prior to landing. 20' trees on both sides of rwy within 60-70' of centerline. Rwy 09-27 rocks up to 6" on sfc. No services avbl.

**AIRPORT MANAGER:** (907) 451-5280

**COMMUNICATIONS:** CTAF 122.9

**COMM/NAV/WEATHER REMARKS:** For a toll free call to Fairbanks FSS dial 1-866-248-6516, for local call to Fairbanks FSS dial 907-474-0137.

**LAKLOEY AIR PARK** (AK22) PVT 6 E UTC-9(-8DT) N64°49.30' W147°31.30' **FAIRBANKS**

475 NOTAM FILE Not insp.

**RWY 06-24:** 4000X50 (GRVL)

**RWY 06:** Trees. Rgt tfc.

**AIRPORT REMARKS:** Unattended. Rwys not maintained or monitored, recommend visual inspection prior to using. No facilities. Unusable for wheels in the fall, winter, spring. PPR for transient acct, write to Lakloey Airpark, P.O. Box 58388, Fairbanks AK 99711.

**AIRPORT MANAGER:** 907-488-1724

**COMMUNICATIONS:** CTAF 125.0

**COMM/NAV/WEATHER REMARKS:** For a toll free call to Fairbanks FSS dial 1-866-248-6516, for local call to Fairbanks FSS dial 907-474-0137.

**WATERWAY 06W-24W:** 3400X100 (WATER)

**WATERWAY 06W:** Trees. Rgt tfc.

**METRO FLD** (MTF) PVT 2 S UTC-9(-8DT) N64°48.41' W147°45.75' **FAIRBANKS**

432 TPA-1000(568) NOTAM FILE

**RWY 06-24:** H4600X80 (ASPH-GRVL)

**RWY 06:** Road. Rgt tfc.

**AIRPORT REMARKS:** Unattended. Rwy 06-24 2600 ft x 30 ft paved on Rwy 06 end. Pavement very rough. Rwy condition not monitored, recommend visual inspection prior to use. 140' crane btn rwy and float pond summer months. Ditch and berm 40' from Rwy 06.

**AIRPORT MANAGER:** 907-388-3053

**WEATHER DATA SOURCES:** SAWRS.

**COMMUNICATIONS:** CTAF 118.3

SUAIS 125.3 126.3 (1-800-758-8723).

**COMM/NAV/WEATHER REMARKS:** For a toll free call to Fairbanks FSS dial 1-866-248-6516, for local call to Fairbanks FSS dial 907-474-0137.