

CONTINUED FROM PRECEDING PAGE

RADIO AIDS TO NAVIGATION: NOTAM FILE FAI.
(H) (H) **VORTACW** 108.6 FAI Chan 23 N64°48.00' W148°00.72' 056° 4.1 NM to fld. 1526/21E.
TACAN AZIMUTH unusable:
065°-100° byd 30 NM
270°-330° byd 10 NM blo 10,000'
270°-330° byd 30 NM
CHENA NDB (HW) 257 CUN N64°50.32' W147°29.70' 245° 9.4 NM to fld. 462/17E.
ILS/DME 109.1 I-CNA Chan 28 Rwy 02L. Class IIIE. DME unusable byd 025° left of course.
ILS/DME 110.3 I-FAI Chan 40 Rwy 20R. Class IIE.
COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1-866-248-6516, for a local call to Fairbanks FSS dial (907) 474-0137. TACAN located N64°48.01' W148°00.81'. (Although colocated facilities antennae are at different positions). For flights in MOA's east of Fairbanks recommend contacting Eielson Range Control on 125.3/126.3 or call 1-800-758-8723 for information on military activities. NWS weather balloon launch site 2000 feet west of midfield Runway 02L-20R. Launches are twice daily at 1100 and 2300 UTC.
* * * * *

WATERWAY 02W-20W: 5400X100 (WATER)
WATERWAY 02W: Fence.
WATERWAY 20W: Fence.
SEAPLANE REMARKS: Waterlane is controlled; ctc ATCT on freq 118.3 for approval. Waterlane threshold buoys are 500 from N and S shores and mark waterlane. Step taxi prohibited outside of waterlane. East of waterlane is uncontrolled; aircraft may taxi in this area at pilot discretion. Recommend ctc clnc del as soon as practical after eng start. Sfc frozen in winter, not monitored. Limited transient float plane parking avbl ctc 907-455-4571. Migratory birds in the vicinity of arpt during Spring thru Fall.

GOLD KING CREEK (AK7)(PAAN) 39 SE UTC-9(-8DT) N64°11.88' W147°55.72' **FAIRBANKS**
1720 NOTAM FILE FAI
RWY 09-27: 2558X17 (GRVL-DIRT)
RWY 09: Trees.
RWY 27: Brush.
AIRPORT REMARKS: Unattended. Rwy condition not monitored, recommend visual inspection prior to landing. 20' trees on both sides of rwy within 60-70' of centerline. Rwy 09-27 rocks up to 6" on sfc. No services avbl.
AIRPORT MANAGER: (907) 451-5280
COMMUNICATIONS: CTAF 122.9
COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1-866-248-6516, for local call to Fairbanks FSS dial 907-474-0137.

LAKLOEY AIR PARK (AK22) PVT 6 E UTC-9(-8DT) N64°49.30' W147°31.30' **FAIRBANKS**
475 NOTAM FILE Not insp. **H-1B, L-3A, 3D, 4J**
RWY 06-24: 4000X50 (GRVL)
RWY 06: Trees. Rgt tfc.
AIRPORT REMARKS: Unattended. Rwys not maintained or monitored, recommend visual inspection prior to using. No facilities. Unusable for wheels in the fall, winter, spring. PPR for transient acft, write to Lakloey Airpark, P.O. Box 58388, Fairbanks AK 99711.
AIRPORT MANAGER: 907-488-1724
COMMUNICATIONS: CTAF 125.0
COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1-866-248-6516, for local call to Fairbanks FSS dial 907-474-0137.
* * * * *

WATERWAY 06W-24W: 3400X100 (WATER)
WATERWAY 06W: Trees. Rgt tfc.

METRO FLD (MTF) PVT 2 S UTC-9(-8DT) N64°48.41' W147°45.75' **FAIRBANKS**
432 TPA-1000(568) NOTAM FILE **H-1B, L-3A, 3D, 4J**
RWY 06-24: H4600X80 (ASPH-GRVL)
RWY 06: Road. Rgt tfc.
AIRPORT REMARKS: Unattended. Rwy 06-24 2600 ft x 30 ft paved on Rwy 06 end. Pavement very rough. Rwy condition not monitored, recommend visual inspection prior to use. 140' crane btn rwy and float pond summer months. Ditch and berm 40' from Rwy 06.
AIRPORT MANAGER: 907-388-3053
WEATHER DATA SOURCES: SAWRS.
COMMUNICATIONS: CTAF 118.3
SUAS 125.3 126.3 (1-800-758-8723).
COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1-866-248-6516, for local call to Fairbanks FSS dial 907-474-0137.