CHENA RIVER SPB (2Z5) 3 W UTC–9(–8DT) N64°49.97′ W147°50.90′ **FAIRBANKS**
440 TPA—1000(560) NOTAM FILE FAI
WATERWAY N–S: 5000X300 (WATER)
WATERWAY E–W: 3000X300 (WATER)
SEAPLANE REMARKS: Unattended. Operating area in Chena River north and west of Fairbanks Intl arpt. PVT 900′ X 50′ grass strip adjacent river. All property along river bank is privately owned. Public access to river consists of one small gravel ramp. Public access ramp is at north end of Ravenwood Ave. N64–49.9′ W147–52.5′
COMMUNICATIONS: CTAF 122.9
COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1–866–248–6516, for local call to Fairbanks FSS dial 907–474–0137.

FAIRBANKS INTL (FAI)(PAFA) 3 SW UTC–9(–8DT) N64°48.92′ W147°51.40′ **FAIRBANKS**
439 B LRA Class I, ARFF Index C NOTAM FILE FAI **H–1B, 2K, L–3A, 3D, 4J**
RWY 02L–20R: H11800X150 (ASPH–GRVD) S–75, D–220, 2D–580, **IAP, DIAP, AD**
2D/2D2–1100 PCR 780 F/B/X/T HIRL CL
RWY 02L: ALSF2. TDZL. PAPI(P4L)—GA 3.0° TCH 73′. RVR–TMR Thld dsplcd 750′. Tree.
RWY 20R: MALSR. PAPI(P4L)—GA 3.0° TCH 74′. RVR–TMR Thld dsplcd 750′. Tree.
RWY 02R–20L: H4510X75 (ASPH) S–21, D–40 PCR 46 F/B/X/T MIRL
RWY 02R: PAPI(P4L)—GA 3.0° TCH 40′. Trees. Rgt tfc.
RWY 20L: REIL. PAPI(P4L)—GA 3.0° TCH 42′.
RWY 02–20: 2900X75 (GRVL)
RUNWAY DECLARED DISTANCE INFORMATION
RWY 02L:TORA–11800 TODA–12800 ASDA–11800 LDA–11050
RWY 20R:TORA–11800 TODA–12800 ASDA–11800 LDA–11050
SERVICE: S4 **FUEL** 100LL, JET A1 **OX** 1, 2 **LGT** Rwy 20R PAPI unusable byd 8° right of centerline.
NOISE: Noise abatement procedures in efct 0700–1700Z‡; lrg, turbine & hvy arr Rwy 02L; dep Rwy 20R based on wind. Eng runup lct –arpt ops.
AIRPORT REMARKS: Attended continuously. Birds invof Spring–Fall. Ctn: Avoid lndg on twy; N/S twy parl to Rwy 02L/20R w side. Tnst prkg wingspan less than 79 ft E ramp. Tsnt prkg W ramp NA. Ltd tsnt float plane prkg—907–455–4571. Medivac and tsnt hel prkg—907–750–0890. Ctn: Snow removal equip Oct 1 to May 15. Mil contr fuel avbl. Tfc pat alt (single engine reciprocating acft) 1500′ MSL. Tfc pat alt (all multi–engine, large and turbine–powered acft) 2000′ MSL. Rwy 02R–20L is limited for use by acft design Group B II, acft or smaller. Rwy 02–20 summer and ski strip winter use; avbl lcl NOTAM and ATCT bfr arr or dep. Rwy 02W/20W ctld; apreq—ATCT 118.3. Ctc CD asap aft eng start. Frozen in winter; sfc unmnt. Thr buoys 500 ft fm N & S shore mark waterlane. Step tax outside of waterlane NA. E of waterlane unctld; tax at pilot discretion. PPR mil ops hvy cargo or trml apn –arpt ops. Twy B scty gate btn Rwy 02L–20R and Twy C avbl to wingspan 79 ft or less; ACTVT – 5 clicks 121.75. If inop—907–750–0890. Compass rose not calibrated. SAID in use. Operate transponders with altitude reporting mode and ADS–B (if equipped) enabled on all airport surfaces. Cold temperature airport. Altitude correction required at or below –29C. See addnl pages under Notices for TRSA and Fairbanks area info.
AIRPORT MANAGER: 907-474-2500
WEATHER DATA SOURCES: ASOS 124.4 (907) 621–7609. (WX CAM)
COMMUNICATIONS: SFA ATIS 124.4 907–456–1244) (TIE–IN FSS FAIRBANKS FAI–NOTAM FAI)
RADIO 122.2 124.1 132.65 (E)
Ⓡ **APP CON** 125.35 363.2 (180°–359°) 127.1 251.1 (360°–179°) 119.85 (E)
TOWER 118.3 257.8 (E) **GND CON** 121.9 **CLNC DEL** 127.6
Ⓡ **DEP CON** 125.35 363.2 (180°–359°) 127.1 251.1 (360°–179°) 327.1 (E)
SUAIS (Eielson Range Control) 125.3.
AIRSPACE: CLASS D.
TRSA svc ctc **APP CON**

CONTINUED ON NEXT PAGE

CONTINUED FROM PRECEDING PAGE

RADIO AIDS TO NAVIGATION: NOTAM FILE FAI.

(VH) (H) VORTACW 108.6 FAI Chan 23 N64°48.00´ W148°00.72´ 056° 4.1 NM to fld. 1526/21E.

TACAN AZIMUTH unusable:
065°–100° byd 30 NM
270°–330° byd 10 NM blo 10,000´
270°–330° byd 30 NM

VOR unusable:
121°–131° byd 40 NM
184°–186° byd 40 NM blo 10,000´
194°–200° byd 40 NM blo 5,000´
194°–200° byd 62 NM
280°–286° byd 40 NM
290°–300° byd 40 NM
301°–311° byd 40 NM blo 9,000´
312°–336° byd 40 NM
345°–349° byd 40 NM
350°–355° byd 40 NM blo 7,000´
350°–355° byd 65 NM

CHENA NDB (HW) 257 CUN N64°50.32´ W147°29.70´ 245° 9.4 NM to fld. 462/17E.

ILS/DME 109.1 I–CNA Chan 28 Rwy 02L. Class IIIE. DME unusable byd 025° left of course.

ILS/DME 110.3 I–FAI Chan 40 Rwy 20R. Class IIE.

COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1–866–248–6516, for a local call to Fairbanks FSS dial (907) 474–0137. TACAN located N64°48.01´ W148°00.81´. (Although colocated facilities antennae are at different positions). Ops in MOA´s e of Fairbanks– Eielson Range Control 125.3/126.3 or 1–800–758–8723. Wx bln launch 2000 ft W of midfield Rwy 02L–20R; 1100 and 2300 dly.

WATERWAY 02W–20W: 5400X100 (WATER)

WATERWAY 02W: Fence.

WATERWAY 20W: Fence.

SEAPLANE REMARKS: Waterlane is controlled; ctc ATCT on freq 118.3 for approval. Waterlane threshold buoys are 500 from N and S shores and mark waterlane. Step taxi prohibited outside of waterlane. East of waterlane is uncontrolled; aircraft may taxi in this area at pilot discretion. Recommend ctc clnc del as soon as practical after eng start. Sfc frozen in winter, not monitored. Limited transient float plane parking avbl ctc 907–455–4571. Migratory birds in the vicinity of arpt during Spring thru Fall.

GOLD KING CREEK (AK7)(PAAN) 39 SE UTC–9(–8DT) N64°11.88´ W147°55.72´ FAIRBANKS

1720 NOTAM FILE FAI

RWY 09–27: 2558X17 (GRVL–DIRT)

RWY 09: Trees.

RWY 27: Brush.

AIRPORT REMARKS: Unattended. Rwy condition not monitored, recommend visual inspection prior to landing. 20´ trees on both sides of rwy within 60–70´ of centerline. Rwy 09–27 rocks up to 6" on sfc. No services avbl.

AIRPORT MANAGER: (907) 451-5280

COMMUNICATIONS: CTAF 122.9

COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1–866–248–6516, for local call to Fairbanks FSS dial 907–474–0137.

LAKLOEY AIR PARK (AK22) PVT 6 E UTC–9(–8DT) N64°49.30´ W147°31.30´ FAIRBANKS

475 NOTAM FILE Not insp. H–1B, L–3A, 3D, 4J

RWY 06–24: 4000X50 (GRVL)

RWY 06: Trees. Rgt tfc.

AIRPORT REMARKS: Unattended. Rwys not maintained or monitored, recommend visual inspection prior to using. No facilities. Unusable for wheels in the fall, winter, spring. PPR for transient acft, write to Lakloey Airpark, P.O. Box 58388, Fairbanks AK 99711.

AIRPORT MANAGER: 907-488-1724

COMMUNICATIONS: CTAF 125.0

COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1–866–248–6516, for local call to Fairbanks FSS dial 907–474–0137.

WATERWAY 06W–24W: 3400X100 (WATER)

WATERWAY 06W: Trees. Rgt tfc.
