


VOR/DME OTM	APP CRS	Rwy Ldg TDZE	6001
111.6	124°	842	
Chan 53		Apt Elev	846

VOR RWY 13
OTTUMWA RGNL (OTM)

DME required.	MISSED APPROACH: Climb to 3000 direct OTM VOR/DME and hold, continue climb-in-hold to 3000.
---------------	---

ASOS 124.175	CHICAGO CENTER 118.15 335.575	UNICOM 123.0 (CTAF) 0
-----------------	----------------------------------	--------------------------



ELEV 846	TDZE 842
----------	----------

