

**TOP ALTITUDE:
ASSIGNED BY ATC**

ALEXANDRIA
116.1 AEX
Chan 108
N31°15.40'
W92°30.06'

LUFKIN
112.1 LFK
Chan 58

COSGO
N31°13.26'
W93°27.16'

VELCO
N31°10.67'
W94°24.55'
10000

V212
J50

V212
J50

FL190
095°
(187)

MC COMB
116.7 MCB
Chan 114
N31°18.27'
W90°15.49'
L-21-22, H-6

CRESTVIEW
115.9 CEW
Chan 106
N30°49.57'
W86°40.75'
L-21-22, H-6

POLK
108.4 FXU


DAISETTA
116.9 DAS
Chan 116

RAECN
N30°05.08'
W95°14.95'

HUMBLE
116.6 IAH
Chan 113

MUSIQ
N30°33.17'
W94°53.53'

DARTR
N30°24.19'
W95°00.41'



NOTE: RADAR required.
NOTE: The following TRANSITIONS are ATC assigned only. Do not file.
CRESTVIEW TRANSITION: (For aircraft being weather rerouted to join a jet route off CEW VORTAC or overflying CEW VORTAC to join a direct route).
MC COMB TRANSITION: (For aircraft being weather rerouted to join a jet route off MCB VORTAC or overflying MCB VORTAC to join a direct route).

TAKEOFF MINIMUMS
Rwys 5, 12, 23, 30: Standard.

(NARRATIVE ON FOLLOWING PAGE)

CLNC DEL
125.6
CTAF
122.7
HOUSTON DEP CON
134.45 284.0



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 5: Climb on heading 046° to 500 before turning. When entering controlled airspace, climb on assigned heading for RADAR vectors to RAECN INT. Maintain ATC assigned altitude. Expect filed altitude 10 minutes after departure, thence. . . .

TAKEOFF RUNWAY 12: Climb on heading 121° to 500 before turning. When entering controlled airspace, climb on assigned heading for RADAR vectors to RAECN INT. Maintain ATC assigned altitude. Expect filed altitude 10 minutes after departure, thence. . . .

TAKEOFF RUNWAY 23: When entering controlled airspace, climb on assigned heading for RADAR vectors to RAECN INT. Maintain ATC assigned altitude. Expect filed altitude 10 minutes after departure, thence. . . .

TAKEOFF RUNWAY 30: Climb on heading 301° to 700 before turning. When entering controlled airspace, climb on assigned heading for RADAR vectors to RAECN INT. Maintain ATC assigned altitude. Expect filed altitude 10 minutes after departure, thence. . . .

. . . .on IAH R-028 to VELCO INT, cross VELCO INT at or above 10000, then right turn on LFK R-082 and AEX R-265 to AEX VORTAC.

CRESTVIEW TRANSITION (AEX3.CEW): From over AEX VORTAC on AEX R-085 and MCB R-266 to MCB VORTAC, then on MCB R-095 and CEW R-277 to CEW VORTAC.

MC COMB TRANSITION (AEX3.MCB): From over AEX VORTAC on AEX R-085 and MCB R-266 to MCB VORTAC.