

|            |             |             |
|------------|-------------|-------------|
| LOM CX     | APP CRS     | Rwy Ldg     |
| <b>281</b> | <b>140°</b> | <b>7501</b> |
|            |             | TDZE        |
|            |             | <b>236</b>  |
|            |             | Apt Elev    |
|            |             | <b>245</b>  |

NDB RWY 14  
CONROE/NORTH HOUSTON RGNL (CXO)




▼

▲

MALSR

MISSED APPROACH: Climb to 1000 then climbing left turn to 2100 direct ALIBI LOM and hold.

|                        |                                       |                                          |                          |
|------------------------|---------------------------------------|------------------------------------------|--------------------------|
| ATIS<br><b>118,325</b> | HOUSTON APP CON<br><b>119.7 281.4</b> | CONROE TOWER★<br><b>124,125 (CTAF) 0</b> | GND CON<br><b>120,45</b> |
|------------------------|---------------------------------------|------------------------------------------|--------------------------|



| CATEGORY | A                     | B | C                         | D                 |
|----------|-----------------------|---|---------------------------|-------------------|
| S-14     | 880-3/4 644 (700-3/4) |   | 880-1 3/8 644 (700-1 3/8) |                   |
| CIRCLING | 880-1 635 (700-1)     |   | 880-1 7/8 635 (700-1 7/8) | 960-2 715 (800-2) |